

Roger Access Control System

MCT68ME-IO Reader

Installation Manual

Hardware version: v2.x
Firmware version: 2.1.0.307 and newer

Document version: Rev. G

This document contains minimum information that is necessary for initial setup and installation of the device. The detailed description of configuration parameters and functionalities is specified in respective Operating Manual available at www.roger.pl. This document is subject to the Terms of Use in the current version published on the website www.roger.pl. The manufacturer reserves the right to make changes to the product without prior notice. © ROGER sp. z o. o. sp.k. All rights reserved.

INTRODUCTION

The reader is designed for operation with MC16 access controller (RACS 5 system). Factory new reader is configured with default settings including ID=100 address. MCT68ME reader is available in indoor and outdoor versions. The latter one is equipped with additional, protecting metal enclosure.

DEVICE CONFIGURATION

The reader can be configured in regard of various parameters (including address) in order to adapt it to the requirements of specific installation. Device can be configured from VISO v2 management software or RogerVDM utility software.

CONFIGURATION WITH VISO v2 PROGRAM

In RACS 5 v2 system the reader can be installed at site without previous configuration. According to AN006 application note, its address and other settings can be configured from VISO v2 management software and during such configuration the access to its service contacts (fig. 2) is not required.

CONFIGURATION WITH ROGERVDM PROGRAM




Fig. 1 Connection of MCT terminal to RUD-1 interface

Programming procedure:

1. Connect the device to RUD-1 interface (fig. 1) and connect the RUD-1 to computer's USB port.
2. Start RogerVDM program, select *MCT* device, firmware version, *RS485* communication channel and serial port with RUD-1 interface.
3. Click *Connect*, the program will establish connection and will automatically display *Configuration* tab.
4. Enter unoccupied *RS485* address in range of 100-115 and other settings according to requirements of specific installation.
5. Click *Send to Device* to update the configuration of device.
6. Optionally make a backup by clicking *Send to File...* and saving settings to file on disk.
7. In the top menu select *Device->Disconnect*.
8. Disconnect device from RUD-1 interface.

Note: Do not use the keypad or read any cards when reader is configured with RogerVDM..

MEMORY RESET

Memory reset procedure enables configuration of *RS485* address and resets all other settings to factory default ones.

Memory reset procedure:

1. Remove all connections from A and B lines.
2. Place jumper on MEM contacts (fig. 2)
3. Restart the device (switch power supply off and on or short RST contacts for a moment).
4. When 'CONFIG RESET' is displayed by reader then remove jumper from MEM contacts.
5. When 'ID:' is displayed by reader then enter 3 digits of *RS485* address in range of 100-115 with reader keypad.
6. When the third digit is defined then the reader will restart with the new address.

FIRMWARE UPDATE

The update requires connection of reader to computer with RUD-1 interface (fig. 1) and starting RogerISP software. The latest firmware file is available at www.roger.pl.

Note: Backup configuration with RogerVDM software before firmware update because the update will restore factory default settings.

Note: During the firmware update process, it is necessary to ensure continuous and stable power supply for the device. If interrupted the device may require repair by Roger.

Firmware update procedure:

1. Connect the reader to RUD-1 interface (fig. 1) and connect the RUD-1 to computer's USB port.
2. Place jumper on FDM contacts (fig. 2).
3. Restart the reader (switch power supply off and on or short RST contacts for a moment).
4. Start RogerISP program.
5. Select serial port with RUD-1 interface and *USB-RS485 Converter* option.
6. Specify path to firmware file (*.hex).
7. Click *Program* and proceed according to displayed messages.
8. Remove jumper from FDM contacts and restart the reader.

INSTALLATION




Fig. 2 Service contacts.

| Table 1. Screw terminals | | |
|--------------------------|-------------------|--------------|
| Screw terminal | Description | Wire color |
| 12V | Supply plus | Red |
| GND | Ground | Black |
| IN1 | IN1 input line | Pink |
| IN2 | IN2input line | Blue |
| IN3 | IN3 input line | White/Yellow |
| RS485 A | RS485 bus, line A | Brown |
| RS485 B | RS485 bus, line B | White/Green |
| CLK | Not used | White |
| DTA | Input/output line | Green |
| TMP | Tamper contact | Yellow |
| TMP | Tamper contact | Gray |
| IO1 | IO1 output line | Yellow/Brown |
| IO2 | IO2 output line | Brown/Green |

| | | |
|----------|----------------------------|-----------|
| REL1-NC | REL1 relay output (NC) | Gray/Pink |
| REL1-COM | REL1 relay common terminal | Red/Blue |
| REL1-NO | REL1 relay output (NO) | Purple |

Installation guidelines

- The terminal should be mounted on a vertical structure (wall) away from sources of heat and moisture.
- Front panel should be attached in such way as the tamper detector would firmly press the back panel.
- In particular, it is not allowed to install the reader in places with high humidity such as saunas, swimming pools, car washes, etc.
- All electrical connections should be done with disconnected power supply.
- If the device is installed in a place exposed to conductive dust (e.g. metal dust), protect the MEM/RST/FDM pins with insulating mass, e.g. silicone, after installation.
- If the terminal and controller are not supplied from the same PSU then GND terminals of both devices must be connected with any wire.
- Device can be cleaned by means of wet cloth and mild detergent without abrasive components. In particular do not clean with alcohols, solvents, petrol, disinfectants, acids, rust removers, etc. Damages resulting from improper maintenance and usage are not covered by manufacturer warranty.




Fig. 3 MCT68ME-IO-I installation.




Fig. 4 MCT68ME-IO-I installation.

APPENDIX

| Table 2. Specification | |
|------------------------|--|
| Nominal supply voltage | 12VDC |
| Nominal supply current | ~100 mA |
| Inputs | Three NO/NC inputs (IN1..IN3) internally connected to the power supply plus through a 15kΩ resistor, approx. 3.5V triggering level |
| Relay output | Relay output (REL1) with single NO/NC contact, 30V/1.5A DC/AC max. load |
| Transistor outputs | Two (IO1, IO2) open collector outputs, 15VDC/150mA max. load |
| DTA input/output | I/O line configured as NO/NC input or open collector output with 15VDC/15mA max. load |
| Tamper protection | Isolated 24V/50mA contacts, shorted when enclosure is closed |
| Identification methods | EM 125 kHz UNIQUE according to EM4100/4102 and 13.56MHz according to ISO14443A and MIFARE |
| Reading range | Up to 10 cm for EM125kHz Up to 7 cm for MIFARE |
| Distance | 1200 m maximal cable length for RS485 bus between controller and terminal |
| IK | IK05 |
| IP | MCT68ME-IO-I: IP30 MCT68ME-IO-O: IP54 |
| Environment | MCT68ME-IO-I: Indoor general conditions, temperature: +5°C to +40°C, relative humidity: 10 to 75% (no condensation) MCT68ME-IO-O: Outdoor general conditions, temperature: -25°C to |

| | |
|-------------------------|---|
| | +60°C, relative humidity: 10 to 75% (no condensation) |
| Dimensions HWD | MCT68ME-IO-I: 170 x 110 x 42 mm MCT68ME-IO-O: 220 x 156 x 104 mm |
| Weight | MCT68ME-IO-I: ~410g MCT68ME-IO-O: ~1150g |
| Compliance | CE, RoHS |
| Manufacturer's warranty | 36 months |



This symbol placed on a product or packaging indicates that the product should not be disposed of with other wastes as this may have a negative impact on the environment and health. The user is obliged to deliver equipment to the designated collection points of electric and electronic waste. For detailed information on recycling, contact your local authorities, waste disposal company or point of purchase. Separate collection and recycling of this type of waste contributes to the protection of the natural resources and is safe to health and the environment. Weight of the equipment is specified in the document.




Fig. 5 Connection of terminals and expanders to MC16 access controller

| Table 3. Ordering information | |
|-------------------------------|---|
| MCT68ME-IO-I | Access terminal; EM 125 kHz and 13.56 MHz MIFARE® (CSN); communication interface RS485 EPSO 3 (RACS 5); keyboard; I/O lines; 12 VDC supply; RADIUS series line; indoor version |
| MCT68ME-IO-O | Access terminal; EM 125 kHz and 13.56 MHz MIFARE® (CSN); communication interface RS485 EPSO 3 (RACS 5); keyboard; I/O lines; 12 VDC supply; RADIUS series line; outdoor version with metal protection enclosure |
| RUD-1 | Portable USB-RS485 communication interface dedicated to ROGER access control devices |

| Table 4. Product history | | |
|--------------------------|---------|---|
| Version | Date | Description |
| MCT68ME-IO-I v1.0 | 09/2016 | The first commercial version of product |
| MCT68ME-IO-I v2.0 | 01/2018 | Modifications of electronic components |
| MCT68ME-IO-O v1.0 | 09/2016 | The first commercial version of product |
| MCT68ME-IO-O v2.0 | 01/2018 | Modifications of electronic components |
| MCT68ME-IO-O v2.1 | 11/2019 | Modification of ME-7 metal enclosure |
| MCT68ME-IO-O v2.2 | 02/2025 | Enclosure modifications |

Contact:
Roger Sp. z o. o. sp. k.
82-400 Sztum
Gościszewo 59
Tel.: +48 55 272 0132
Fax: +48 55 272 0133
Tech. support: +48 55 267 0126
E-mail: support@roger.pl
Web: www.roger.pl