
Roger Access Control System

PS1A-LCK power supply module Operating Manual

Product version: 1.0
Firmware version: n/a
Document version: Rev. A



rcdr276

Design and application

PS1A-LCK module is dedicated to provide power supply for the second door if built-in power supply unit of the MC16 controller or MCX402DR expander is sufficient for only single door. The module is supplied with 18VAC and it offers 13.8VDC at LCK and TML outputs. The LCK (1.0A) output is dedicated to supply door lock and it can be triggered with LCKEN input. Optionally it can be triggered all the time and used to supply door related devices e.g. alarm signalling, door bell. The TML (0.2A) output is dedicated to supply readers and is triggered all the time. PS1A-LCK can be connected to backup battery in order to offer emergency supply for door. The shortage of 18VAC power supply is signalled with ACL transistor (open collector) output. All PS1A-LCK outputs are protected against overload. PS1A-LCK is offered individually as electronic module or as a component of MCX402-2-KIT.





Fig. 1 Functional diagram of PS1A-LCK module







Fig. 2 PS1A-LCK installation with MC16 access controller (A) and MCX402DR expander (B)

Characteristics

- Power supplied from 18VAC transformer
- Power output 13.8VDC/1.0A
- Power output 13.8VDC/0.2A
- LCK output control with LCKEN input
- 18VAC power supply shortage signalling output

Power supply and backup battery

PS1A-LCK module is supplied through AC terminals and red LED indicator is located at the AC+ terminal to signal the voltage at the input. The module can be supplied from own 18VAC/20VA transformer or the same transformer which supplies MC16 controller or MCX402DR expander. In such case the power of transformer must be sufficient to ensure supply to all devices. Positive pole of the battery connected to the controller/expander must be also connected to module BAT+ terminal. Do not connect battery negative pole to the module. PS1A-LCK ground must be connected with controller/expander ground.






Fig 3. PS1A-LCK power supply from single transformer (A) or two transformers (B)

LCK output and LCKEN input

LCK output is dedicated to supply door lock. The output can be triggered with LCKEN input which on the other hand can be triggered by transistor or relay output with minimal rating 15V/5mA at the controller/expander. When LCKEN is shorted to ground then LCK is triggered. If the input is shorted to ground constantly then LCK output could be used to supply door related devices such as alarm signalling, door bell, etc. The terminal LCK+ is protected with 1.0A electronic fuse. The terminal LCK- is internally shorted to ground. Green LED indicator is located at the LCK+ terminal to signal voltage at the output.

TML power output


TML power supply output is dedicated to supply readers at doors. The terminal TML+ is protected with 0.2A electronic fuse . The terminal TML- is internally shorted to ground. Green LED indicator is located at the TML+ terminal to signal voltage at the output.

ACL signalling output

ACL output is triggered in case of 18VAC power supply shortage and it can switch up to 40mA current at 15V. MC16 controller and MCX402DR expander monitor their power supply thus ACL output is used only if PS1A-CLK is supplied from its own transformer.

Door control and connection to controller/expander

The module offers 13.8VDC power supply to readers and door lock when supplied from 18VAC transformer. LCK output can be controlled in two alternative ways according to fig. 4. Transistor output or relay can be used to control the lock.







Fig. 4 Typical scenarios of door lock control with PS1A-LCK






Fig. 5 Door lock and alarm signalling device (siren) control with relays (A) or transistor outputs (B)

Installation

Enclosure with DIN rail is recommended for installation of PS1A-LCK power module. All electric connections must be done without voltage on wires/terminals and with power supply disconnected. Optionally, DIN rail mounting clips can be removed and the module can be installed on flat surface. It is recommended to install the module in the same enclosure as controller/expander.




Fig. 6 PS1A-LCK board

PS1A-LCK terminals	CK terminals	
Terminal	Function	
LCK+	13.8VDC/1.0A output power positive pole	
LCK-	13.8VDC/1.0A output power negative pole	
LCKEN	LCK output control input	
TML+	13.8VDC/0.2A output power positive pole	
TML-	13.8VDC/0.2A output power negative pole	
GND	PS1A-LCK ground internally shorted with LCK- and TML- terminals	
BAT+	Battery positive pole	
ACL	18VAC power failure signalling output	
AC	18VAC power input	
AC	18VAC power input	

Specification

Parameter	Value
Power supply voltage	18VAC min. 20VA
LCK power output for door lock	13.8VDC/1.0A; overload protection
TML power output for readers	13.8VDC/0.2; overload protection
ACL output for power shortage signalling	15VDC/40mA; overload protection
LCKEN input	Triggering <1V
Environmental class	Class I, indoor general conditions, temperature: +5°C to +40°C, relative humidity: 10 to 95% (no condensation)
Dimensions	40 x 80 mm
Weight	45 g


Certificates	CE	
o o i i i i o o o o o o o o o o o o o o		

Ordering information

Product	Description	
PS1A-LCK	S1A-LCK Door lock power supply module	

Product history

Version	Date	Description
PS1A-LCK v1.0	10/2017	The first commercial version of the product



This symbol placed on a product or packaging indicates that the product should not be disposed of with other wastes as this may have a negative impact on the environment and health. The user is obliged to deliver equipment to the designated collection points of electric and electronic waste. For detailed information on recycling, contact your local authorities, waste disposal company or point of purchase. Separate collection and recycling of this type of waste contributes to the protection of the natural resources and is safe to health and the environment. Weight of the equipment is specified in the document..

Contact:

Roger sp. z o.o. sp.k. 82-400 Sztum Gościszewo 59 Tel.: +48 55 272 0132

Fax: +48 55 272 0133
Tech. support: +48 55 267 0126
E-mail: biuro@roger.pl

:-mail: <u>biuro@roger.pl</u> Web: <u>www.roger.pl</u>